



## Selecting The Proper Positioner

### POSITIONER ROTATING CAPACITY



$$\text{Load (Lbs.)} \times \text{Distance (Inches)} = \text{Rotational Torque Rating (Lbs. - Inches)}$$

### POSITIONER TILT CAPACITY



$$\text{Load (Lbs.)} \times (\text{Distance (Inches)} + \text{INH. OH. (Inches)}) = \text{Tilt Torque Rating (Lbs. - Inches)}$$

1. Determine the total weight you will be positioning, including fixtures.
2. Calculate the center of gravity of the work.
  - A. Distance from rotational center.
  - B. Distance from face of table.
3. Using the distance found in step 2-A, calculate the rotational torque required.  
Load (lbs.) x Distance (inches) = Rotational Torque Rating (lbs - inches).
4. Using the distance found in step 2-B, calculate the tilt torque required.  
Load (lbs.) x Distance + INH OH (inches) = Tilt Torque Rating (lbs. - inches).
5. Compare the required rotational and tilt torque with the chart. Select a Positioner with a load capacity equal to or greater than your requirements.

